



# Vex Robotics Summer Camp Day 4





#### Sensors - Basics

What are sensors?

 Robotic sensors are used to estimate a robot's condition and environment. These signals are passed to a controller to enable appropriate

behavior



## Sensors - Basics

Can you name a few sensors in your everyday life?





## Sensors - Basics

- Examples
  - Heart Rate monitor
  - Car lights
  - Microphone
  - Etc






## Sensors - Quadrature encoder

- What is a Quadrature?
  - It is a sensor that measures ticks
  - Needs an axle through it
  - One degree spun is equal to one ticks

Go to "robot"→"motors and sensors" and make a new sensor in "A/D

sensors 1-8"





## Sensors - Quadrature encoder

- The tern "SensorValue" calls on the value the Quadrature is giving
- We first use "SensorValue" to set the Quadrature to zero then we use it for the conditional statement

```
#pragma config(Sensor, dgtl1, rightEncoder,
                                                 sensorQuadEncoder)
#pragma config(Sensor, dgtl3, leftEncoder,
                                            sensorQuadEncoder)
#pragma config(Motor, port2, rightMotor,
                                                    tmotorNormal, openLoop, reversed)
#pragma config(Motor, port3, leftMotor,
                                                    tmotorNormal, openLoop)
//*!!Code automatically generated by 'ROBOTC' configuration wizard
                                                                             !!*//
task main()
 wait1Msec(2000); // 2 Second Delay
 //Clear Encoders
 SensorValue[rightEncoder] = 0;
 SensorValue[leftEncoder] = 0;
 while(SensorValue[leftEncoder] < 1800) // While less than 5 rotations on the leftEncoder...</pre>
   //...Move Forward
   motor[rightMotor] = 63;
   motor[leftMotor] = 63;
```



#### Sensors - Practice

Attach two Quadratures to the robot. Make the robot move forward for 5 rotations, point turn for 2 rotations, the move backwards for


5 rotations





## Sensors - Gyroscope

- The Gyroscope
  - Sensor that tracks degree of rotation on whole robot
  - One tick is equal to ten degrees





# Sensors - Gyroscope


Below, we use the Gyroscope to rotate the robot 90 degrees

```
#pragma config (Motor, port2,
                                                            LeftMotor2.
                                                                           tmotorVex393, openLoop)
                   #pragma config(Motor, port3,
                                                         RightMotor1, tmotorVex393, openLoop, 1
                   #pragma config (Motor, port4,
                                                            RightMotor2, tmotorVex393, openLoop, 1
                   //*!!Code automatically generated by 'ROBOTC' configuration wizard
                   task main()
Aotors
             9
petition Cor
            10
                   //clears our any value the previous port had of the sensor
            11
                   SensorType[in8] = sensorNone;
ote Control
            12
                   wait1Msec(1000);
            13
            14
                   //Sets the port equal to the gyroscope sensor
            15
                   SensorType[in8] = sensorGyro;
            16
                   wait1Msec(2000);
            17
            18
                   int degrees = 900:
            19
                   //90 degrees because 1 tick is equal to ten degrees
            20
            21
                   //turns robot 90 degrees
            22
                   while (abs(sensorValue[in8]) < degrees )
            23
            24
                   motor[LeftMotor1]=25;
                   motor[LeftMotor2]=25;
            26
                   motor[RightMotor1] =-25;
            27
                   motor[RightMotor2] =-25;
            28
            29
            30
            31
```



### Sensors - Practice

Use gyroscope to move robot forward for 5 seconds, turn 180 degrees, then move forward for 10 seconds.





#### Sensors - Buttons

- Buttons on robots take only two values, 0 or 1
- When pressed, button takes value of 1. When it is not pressed, it takes value of 0.





#### Sensors - touch sensors

In the program below, the left and right motor will continuously spin until the button is pressed.

```
#pragma config(Sensor, dgtl6, touchSensor, sensorTouch)
#pragma config(Motor, port2, rightMotor, tmotorNormal, openLoop, reversed)
#pragma config(Motor, port3, leftMotor, tmotorNormal, openLoop)
//*!!Code automatically generated by 'ROBOTC' configuration wizard !!*//


task main()
{
    wait1Msec(2000); // Robot waits for 2000 milliseconds before executing program

    while(SensorValue(touchSensor) == 0) // Loop while robot's bumper/touch sensor isn't pressed in
    {
        motor[rightMotor] = 63; // Motor on port2 is run at half (63) power forward
        motor[leftMotor] = 63; // Motor on port3 is run at half (63) power forward
    }
}
```



#### Sensors - Practice

- Program the robot to move until it hits a wall
- When it hits a wall, make it stop for 5 seconds, move back for 2 seconds, turn right, then continue moving forward.





# Maze Challenge

Using all three sensors we learn, program your robot to move through the maze. The fastest one wins!

